



Specific tool to remove the metal cover for armed fibers F60Mxx type.

1



Remove the external jacket and cut the ke-
vlar. Insert the cable as shown in the photo-
graph.

The cable must be inserted to the beginning
of the external jacket. To fix the cable you
can tighten the upper screw manually or
with the allen key supplied .

If you over tighten the screw you can dama-
ge the fiber optic

2



Tighten the second screw.

3



Keep firm the disk that holds the cable
entry and turn in opposite direction than
helical metal jacket a minimum of 3 laps.

4



Loosen the screw on the disc that has rotated to access the cable and cut the metal jacket without damaging the cable.

5



Remove the disc, so you can proceed to connectorized or splice it.

